

# UROVO CT58S TERMINAL IMPLEMENTATION

Starting from the factory settings, after initializing the terminal and completing the configuration (there is no need to create a Google account), here is the minimum configuration required for the terminal to function properly.

Check for system updates.

Check for updates to Google apps via the Google Play Store and update all apps (required).

## Modifying terminal settings

Click on the blue gear icon on the home screen (bottom left).

### Screen settings

Screen timeout: never

Advanced settings

Screen rotation: disabled

Lift to activate: disabled

### Security settings

App pinning: Enabled

Lock the device when the pin is removed: depending on your needs

### System Settings

Gesture: Quickly open camera: disabled

### Scanner settings

Output mode: Permanent physical keyboard

Sound: None

### Settings **Feature settings**

Hide navigation bar: active

Remove all desktop icons

From Chrome, launch: <https://billetix.net.scan.html>

Click on the three small dots in the top right corner of the screen,

Then Add to Home screen and Install.

When asked to install the application, reply install then ADD TO HOME SCREEN.

Quit Billetix.net and relaunch it via the desktop shortcut.

You can pin the application if you want to lock it to a device.

It is recommended to disable all non- utility services (Bluetooth, NFC etc...) that we do not use in order for the terminal to be more responsive .